

How will I know when a sensor battery is getting low?

As long as you have the sensors set to be "supervised", then the WisDom will alert you via a "Trouble" signal when a battery in a sensor is getting low. See pages 4-17 through 4-18 in the Programming manual to see how to set zone supervision.

Article ID: 29

Last updated: 25 Jan, 2009

Revision: 1

UNRESTRICTED WisDom Information -> How will I know when a sensor battery is getting low?

<http://support.diycontrols.com/index.php?View=entry&EntryID=29>