

# Can I install a FloodStop valve upside down?

FloodStop valves can be installed in any position. These are full port, motorized ball valves; they are not solenoid type valves. Therefore they can be installed in any position.

---

Article ID: 63

Last updated: 26 Mar, 2007

Revision: 1

FloodStop -> Can I install a FloodStop valve upside down?

<http://support.diycontrols.com/index.php?View=entry&EntryID=63>